# The Informal Nature of Systems Engineering

by Gerrit Muller University of South-Eastern Norway-NISE

e-mail: gaudisite@gmail.com

www.gaudisite.nl

#### **Abstract**

The Systems Engineering (SE) discipline is an integrating discipline. SE integrates and guides mono-disciplines, such as mechanical engineering, electrical engineering, and software engineering, to create reliable systems. The SE discipline comprehends multiple approaches:


- well defined formalized SE methods
- strong process focused
- "common sense", based on human experience and intelligence

A balance of these three approaches yields successful products. In this document we will discuss this balance and especially the, often underrated, informal side of SE.


#### Distribution

This article or presentation is written as part of the Gaudí project. The Gaudí project philosophy is to improve by obtaining frequent feedback. Frequent feedback is pursued by an open creation process. This document is published as intermediate or nearly mature version to get feedback. Further distribution is allowed as long as the document remains complete and unchanged.

July 3, 2023 status: planned version: 0




#### **Presentation Outline**






#### Twinscan AT1100






# What is a waferstepper





### From stepping to scanning







# imaging

# line 130 nm width critical dimension


# alignment








### Overlay budget (1999)






# Everything influences overlay






#### What is Formal?






#### **Process: Formal Documents**

#### PRS Product Requirement Spec





#### Formal in Mathematical sense




$$\dot{x}_{s}(t) = \begin{cases} v_{0} & \text{if} & x_{s} < x_{P1} \\ A_{1}x_{s}(t) + B_{1}u(t) & \text{if} & x_{s} \ge x_{P1} \land x_{s} < x_{P2} \\ A_{2}x_{s}(t) + B_{2}u(t) & \text{if} & x_{s} \ge x_{P2} \land x_{s} < x_{P3} \\ A_{3}x_{s}(t) + B_{3}u(t) & \text{if} & x_{s} \ge x_{P3} \land x_{s} < x_{P3} + L \\ 0 & \text{if} & x_{s} \ge x_{P3} + L \end{cases}$$

example PieceWise Linear Systems

Examples of *Hybrid Modeling Formalisms*Björn Bukkems and Marieke Cloosterman
Boderc Symposium 2005



### Fab Context of Waferstepper





#### **Business Context**

value of performance CD control (MHz)

key driver trade-off

business models of the customer: design houses foundries vertical integration other players:
equipments vendors
system integrators
lease companies
fab designers
consultants
mask makers
resist makers
wafer makers
OEM's: laser
intimate partners: lens

Limited number of customers; Many systems per customer



#### **Human Context: Stakeholders**

#### "external"

customer
purchaser
decision maker
user
operator
maintainer

other
government
customer's customer
banks, insurance

#### "internal"


managers
business manager
marketing manager
product manager
operational manager
project leader
sales manager
quality manager
logistics manager
line manager
technology manager

engineers
system engineers
experts
manufacturing engineers
customer support


suppliers
component manufacturer
outsourced design



### Multitude of Disciplines



### Complexity of Waferstepper Context



purchaser system engineers business manager decision maker marketing manager product manager manufacturing engineers operator operational manager customer support maintaine project leader sales manager quality manager logistics manager line manager other component manufacturer technology manager outsourced design customer's customer banks, insurance

engineers

"internal"

managers


stakeholders

#### fab context



waferstepper


# multitude of disciplines



"external"


customer

### Symptom: Delays appear during Integration






#### From Mono-Disciplinary to System






# Exponential Pyramid, from requirement to bolts and nuts





# Waferstepper Example





engineering architecting formal


engineering architecting formal

Skills are much more important than methods

skills of "formal" people: analytical structural firm of principle consistent




#### Multi-disciplinary Research Approaches





#### Conclusion



Systems Engineering:

heterogeneous, the art of ignoring details

Formal Methods: systematic and accurate:

works on well defined homogeneous problems

SE uses FM-thinking: Borrow and Adapt

Formal methods provides input to SE for specific niches

SE sets the boundaries for the application of Formal Methods

